

# Cable Connections for DiamondLink Software

**7011A Serial Connection  
UPS System**




**2033C Serial Connection  
UPS System**




**9800A Serial Connection  
UPS System**



**2033A Serial Connection  
UPS System**



**9700 Serial Connection  
UPS System**



## DiamondLink 6-foot Cable

**UPS END**

**CPU END**



## DiamondLink Extension Cables

(25ft., 50ft., & 100ft. Cables)

**CABLE END**

**CPU END**




# DiamondLink Adapter

CABLE END


UPS END



## 7011A, 2033C, and 9800 Series Connections



## 2033A & 9700 Series Connections



# Extension Cable Connections

(Must use DiamondLink 6-foot cable for software to operate)

